






取扱説明書

圧力検出器（冷媒用）

QBE2x04...

| | | |
|---|--|--|
|  |  | |
|  <p>(注) 取付には別途 UNF ネジアダプターが必要です。</p> |  | |
| <p><配線></p> <div style="display: flex; justify-content: space-around;"> <div data-bbox="199 1668 558 1982"> <p>QBE2004... 0...10 V</p>  </div> <div data-bbox="726 1668 1077 1982"> <p>QBE2104... 4...20 mA</p>  </div> </div> | | |